

Device Selection

Send commands to up to five devices

RCU Setup

Remote Control setup

DVR List

List of recorded programs

Back Arrow

Move back in recording 1 minute

Arrow Controls

DVR playback controls

Menu

Display the Main Menu

Direction Buttons

Move the highlight in system screens

Guide

Displays Channel Guide

Programmable Buttons

Used in some menus

Vol +/-

Adjusts volume

Mute

Turns sound on or off

Number Keys

Select a channel

Swap

Switch picture-in-picture and regular channel

PIP

Turn on or off picture-in-picture

Input

Switch between TV and Video input

Phone

Not currently available

View Live TV

View Live TV

Jump forward

Move forward in recording 30 seconds

Record

Record current program

Info

Displays Info Bar

Exit

Exit Menu or Guide screen

PG +/- and Day +/-

Change Days or Pages within Channel Guide

Ch +/-

Change channels

VOD

Not currently available

Network

Not currently available

Last

Return to previous channel

Keyboard

or On-screen keyboard (not currently available)

Move

Move picture-in-picture

Closed Captioning

Turn on or off closed captioning

SAP

Turn on or off alternative language audio

WWW

Not currently available

